

## RPO Roof Rack Integrated Crossrails

### Kit Contents:              Quantity

Crossrails	2
Instruction Sheet	1

1. Remove the rear end cap covers.
2. Align the cross rail to the end of the side rail.
3. Engage the lever on both sides of the cross rail and slide into the channel of the side rail.
4. Slide the cross rail into the desired position.
5. Replace the rear end cap covers.

Français

### Traverses de galerie de toit intégrées EFC

#### Contenu de la trousse : Quantité

Traverses	2
Fiche de consignes	1

1. Retirer les couvercles d'embout arrière.
2. Aligner la traverse avec l'extrémité du longeron.
3. Engager le levier sur les deux côtés de la traverse et le faire glisser dans la rainure du longeron.
4. Faire glisser la traverse à la position voulue.
5. Remettre les couvercles d'embout arrière en place.

Español

### Riel transversal integrado de la repisa del techo RPO

#### Contenido del kit:              Cantidad

Rieles transversales	2
Hoja de instrucciones	1

1. Desinstale las cubiertas de la tapa del extremo trasero.
2. Alinee el riel transversal al extremo del riel lateral.
3. Enganche la palanca en ambos lados del riel transversal y deslícela en el canal del riel lateral.
4. Deslice el riel transversal a la posición deseada.
5. Reemplace las cubiertas de la tapa del extremo trasero.

